




After removing the appliance from its packaging, check that it and any disassembled parts are undamaged. Before connecting the appliance to the mains, check that the voltage matches that stated on the packaging and in the technical specifications in the instruction manual. The appliance must only be used for the purpose for which it was designed. The manufacturer is not liable for any damage arising from improper use. It is important to keep the instruction booklet.



Risk of electric shock! Incorrect or faulty electrical installation may cause serious injury to people or damage to property. Lamps that need to be directly connected to the mains must only be installed by a qualified electrician.

Warning: Before installing or carrying out any other operations, always disconnect the power supply by switching off the main switch on the electrical panel.



Do not use the appliance without its protective glass. If damaged, replace it immediately.

A dimmer switch cannot be used.

A dimmer switch can be used with this product.

This appliance is compliant with Directive 2014/35/EU.

Appliances designed for direct mounting on normally flammable surfaces.

Downlight. It indicates that the appliance is not suitable for covering with thermal insulation or similar material.

Minimum distance. It indicates the minimum distance that the light source must be kept away from illuminated surfaces and objects (typically flammable).

degree IK – Degrees of protection against external mechanical impacts provided by enclosures for electrical appliances.



Symbols and Protection Classes. Please take note of the following symbols and instructions on the product or packaging to avoid damage due to improper use.

Class 1: lamps with this symbol must be connected to the earth terminal of the mains via the yellow/green wire. **Class 2:** lamps with this symbol are double-insulated and do not require connection to an earth conductor to operate safely. **Class 3:** lamps with this symbol only operate on extra-low safety voltage and must be connected to SELV circuits.



Protection rating.
Standard appliance (for indoor use).



A standardised code indicating the protection level of appliances against the ingress of solid objects and liquids.

Protection against liquids:

- 2 Protected against dripping water falling at an angle of up to 15°.
- 3 Protected against dripping water falling at an angle of up to 60°.
- 4 Protected against dripping water from all directions.
- 5 Protected against water jets from all directions.
- 6 Protected against water jets with a high impact.
- 7 Protected against the effects of immersion.
- 8 Protected against the prolonged effects of immersion under pressure.

Protection against solid objects:

- 2 Protected against solid objects larger than 12 mm.
- 3 Protected against solid objects larger than 2.5 mm.
- 4 Protected against solid objects larger than 1 mm.
- 5 Protected against dust without harmful residue.
- 6 Fully protected against dust:



Installation, Use and Maintenance. Visible damage: Do not switch on or use the appliance if the lamp or the connection cable shows any sign of visible damage.

Modifications: It is strictly forbidden to make any structural or electrical modifications to the lamp or the power cable.

Connection cable: if the external flexible power cable of this appliance is damaged and is not designed to be replaced, the entire lamp must be disposed of.

Replacing the light bulb: always disconnect the appliance from the mains before replacing the light bulb. The lamp and the light bulb reach high temperatures during use: allow them to cool completely before handling. Use only the type of light bulb specified on the appliance, and never exceed the maximum permitted wattage.

Cleaning and care: only clean the appliance when it is switched off and cool. Use a dry or slightly damp cloth, making sure that no moisture comes into contact with the connections or electrical components. Avoid using chemicals or abrasive products that may damage or stain its surfaces.



Disposal and the WEEE Directive

Dispose of the appliance in the correct manner. The crossed-out wheeled bin symbol indicates that old electrical and electronic appliances must not be disposed of with normal household waste. In compliance with current EU regulations, consumers must dispose of end-of-life appliances at the appropriate local recycling centres. If possible, and without damaging the appliance, remove any replaceable light bulbs and batteries (or rechargeable batteries) before disposal, and place them in the appropriate separate waste collection bins. If the appliance contains non-removable built-in batteries, please inform the staff at your local recycling centre. **Smart products:** if the appliance being disposed of contains personal data or network settings, the user is solely responsible for deleting them (perform a factory reset) before disposal. Proper recycling prevents negative impacts on the environment and on public health. **For further information on how to dispose of this product in the correct manner in your country, please visit the website: www.faneurope.it.**